



The maximum 'cable extension' for each section is 800M.
 For example -
 Power supply to the last 1083/55 distributor = 40M
 1083/55 distributor to handset = 15M (multiplied by eg 40 apartments) = 600M.
 40M + 600M = 640M cable extension.
 Cables for electric releases, proximity readers etc are not included in the cable extension calculation.
 The maximum number of sections is 32 therefore the maximum number of apartments is 32 x 50 = 1600

The maximum 'cable extension' for each section is 800M.
 For example -
 Entry panel 1 to power supply = 100M
 Entry panel 2 to power supply = 20M
 Entry panel 3 to power supply = 10M
 Entry panel 4 to power supply = 10M
 Power supply to the last 1083/55 distributor = 40M
 1083/55 distributor to handset = 15M (multiplied by eg 40 apartments) = 600M.
 100M + 20M + 10M + 10M + 40M + 600M = 780M cable extension.
 Cables for electric releases, proximity readers etc are not included in the cable extension calculation.
 The maximum number of sections is 32 therefore the maximum number of apartments is 32 x 50 = 1600

NOTES:

1. This schematic is for guidance only and should not be used for installation
2. Maximum distance from door entry panel to control equipment is 100m using Cat5e cable
3. Maximum distance from control equipment to the furthest handset is 125m using Cat5e cable
4. Maximum distance from the 1083/55 to the handset is 50m using Cat5e cable
5. Spare cores in Cat5e cable must not be used for other services -

