



Installation guide

FDI
URMET|GROUP



Getting started

Page 1

iPassan software management

Page 1

Connecting the PC to the iPassan site

Page 2

iPassan architecture

Page 3

iPassan hardware combinations

Page 5

Products overview

1104/921 (FD-125-002) Controller	Page 6
1104/926 (FD-125-010) 2 Reader expansion card	Page 9
1104/910 (FD-125-015) 10-Input base module	Page 10
1104/913 (FD-125-016) 10-Output base module	Page 11
1104/912 (FD-125-020) 12-Input expansion card	Page 12
1104/914 (FD-125-021) 12-Output expansion card	Page 12
1104/931 (FD020-081) Plastic mullion reader	Page 13
1104/932 (FD020-086) Vandal resistant mullion reader	Page 14
1104/941 (FD-020-191) RF Reciever 868 MHz	Page 15
1104/951 (FD-020-166) Elekta panel mount reader	Page 16
1104/953 (FD-020-007) OEM panel mount reader	Page 16
1104/955 (FD-020-132) Sinthesi Steel reader	Page 16
1104/956 (FD-020-176) Sinthesi S2 reader	Page 16
1104/961 (FD-020-139) P60 reader black	Page 17
1104/962 (FD-020-156) P60 reader white	Page 17
1104/981 (FD-020-178) Keypad	Page 18


iPassan controller connections

Page 19

Getting started

- Install and connect the iPassan controllers and readers – See pages 13 to 22
- Move the **MAINT** jumper to the ‘maintenance’ position – See page 7
- Using an iPassan keyfob, test the operation of the readers and any electric releases, maglocks, exit switches, break glass units etc.
- Move the **MAINT** jumper to the ‘normal’ position – See page 7
- Decide whether the software will be installed on a local PC or if the software will be run from www.ipassan.com – See the iPassan software management explanation below.

- Follow the online ‘Help’ manual



iPassan software management

The iPassan software can either be running on the local PC used to administer the system, or the PC used to administer the system can access the software at www.ipassan.com

In other words, if the iPassan PC *does not have internet access* then the software must be installed locally. If the iPassan PC does have internet access then there is the choice to install the software locally or run the software via www.ipassan.com

A copy of the software is provided on a USB flash drive with the iPassan equipment.


Connecting the PC to the iPassan site

USB connection – single PC




Used when a single PC is directly connected to the first controller to administer the site

Ethernet connection – single PC



Used when a single PC is used to administer the site over a network

Ethernet connection – client/server




Used when multiple PCs are used to administer the site over a network


iPassan architecture

iPassan can be installed in one of three ways -


i. Full IP installation



ii. RS485 installation




iii Hybrid installation




iPassan hardware combinations

iPassan hardware can be configured in the following combinations –




1104/921 – Door Controller (4 readers)



1104/926 – 2 Reader Expansion Card


1104/921 – Door Controller (4 readers)



1104/912 – 12 Input Expansion Card


1104/914 – 12 Output Expansion Card

1104/921 – Door Controller (4 readers)



1104/910 – 10 Input Base Module

1104/913 – 10 Output Base Module




1104/912 – 12 Input Expansion Card

1104/914 – 12 Output Expansion Card

1104/910 – 10 Input Base Module

1104/913 – 10 Output Base Module

1104/921 (FD-125-002) Controller



12V DC supply

12V DC @ 1.0A is required for the controller, plug in 2-door card and six readers.

Ethernet

RJ45 connector for Ethernet interface

RS485 Main


Used for the bus connection between controllers. A maximum of 32 controllers can be connected to the **RS485 Main** bus. The maximum cable distance for the **RS485 Main** bus is 1000M – See page 19

RS485 Aux


Used to connect to Input/Output modules. A maximum of 10 Input/Output base units can be connected to the **RS485 Aux** bus. The maximum cable distance for the **RS485 Aux** bus is 1000M – See page 19

Maintenance jumper

In this position the behaviour of the controller is normal –



When the Maintenance jumper is moved to this position any 13.56Mhz FDI key will operate the relay corresponding to the reader where the key has been used –



This feature is used to test the controller connections before programming is started.

Micro USB connector

Used to connect the PC to the iPassan network

Cabinet tamper

Input for a normally open third party contact, used for example when the controller is mounted in an enclosure.


Built in tamper switch

Activated when the iPassan controller cover is removed. Normally open contact.

Door 1 – Door 4

Reader, exit switch, door contact and lock relay connections.

LED indicators



Server communication

The LED is green when the controller is connected to the server

Main RS485 bus


On the main controller (the controller connected to the server) the red LED is on all the time. On slave controllers it flashes once every three seconds. If there is no communication on the RS485 bus the LED is off.

Auxiliary RS485 bus

The red LED is on when the controller communicates with the input/output expansion modules. When there is no communication on the auxiliary bus the LED is off.

Controller status

The green LED is on when the controller supply voltage is correct. The red LED flashes once per second to indicate the controller is healthy. If the LED is permanently on or permanently off then re-boot the controller.




Red LED

Flashes once every three seconds when the reader is operating correctly.
Flashes three times a second if the reader is not connected, or not communicating with the controller.

Green LED

On all the time that the relay is activated.

1104/926 (FD-125-010) 2 Reader Expansion Card




Red LED

Flashes once every three seconds when the reader is operating correctly.
Flashes three times a second if the reader is not connected, or not communicating with the controller.

Green LED

On all the time that the relay is activated.

1104/910 (FD-125-015) 10-Input Base Module



12V DC supply

12V DC @ 1.0A is required for the 10-Input Base Module

RS485

Used for the bus connection between input/output Base Modules. A maximum of 10 Base Modules can be connected to the **RS485** bus. The maximum cable distance for the **RS485** bus is 1000M – See PAGE 19


IN1 – IN10

Inputs can be via normally open or normally closed clean volt free contacts

+12V OUT

An auxilliary output rated at 200mA

1104/913 (FD-125-016) 10-Output Base Module



12V DC supply

12V DC @ 1.0A is required for the 10-Output Base Module

RS485

Used for the bus connection between input/output Base Modules. A maximum of 10 Base Modules can be connected to the **RS485** bus. The maximum cable distance for the **RS485** bus is 1000M – See Page 19


OUT1 – OUT10

Relays are rated at 48V @ 2A

+12V OUT

An auxilliary output rated at 200mA


1104/912 (FD-125-020) 12-Input Expansion Card



IN1 – IN11 (IN11 – IN22)

Inputs can be via normally open or normally closed clean volt free contacts


1104/914 (FD-125-021) 12-Output Expansion Card




OUT1 – OUT10 (OUT11 – OUT22)

Relays are rated at 48V @ 2A


1104/931 (FD-020-081) reader connections




**1104/921 Controller or
1104/926 2-Reader expansion card**




1104/931 (FD-020-081)




1104/932 (FD-020-086) reader connections



**1104/921 Controller or
1104/926 2-Reader expansion card**




1104/941 (FD-020-191) RF Reciever connections




1104/921 Controller or
1104/926 2-Reader expansion card

1104/941 (FD-020-191)




Terminals **B1+** and **0V** can be connected for example to an automation loop detector (C & NC). This means that the RF key will only work while the vehicle is over the loop. In this case remove the jumper immediately above the **B1+** and **0V** terminals. If this feature is not used then the jumper must remain in place.


**1104/951 (FD-020-166) & 1104/953 (FD-020-007) & 1104/955 (FD-020-132)
& 1104/956 (FD-020-176) reader connections**




1104/961 (FD-020-139) & 1104/962 (FD-020-156) P60 reader connections




**1104/921 Controller or
1104/926 2-Reader expansion card**



**1104/961 (FD-020-139)
1104/962 (FD-020-156)**




1104/981 (FD-020-178) Keypad connections



1104/921 Controller or
1104/926 2-Reader expansion card


1104/981 (FD-020-178)



Controller connections


RS485 bus

RS485 bus using Cat5e STP – Maximum 1000M




It is necessary to use a screened twisted pair cable for example Cat5e STP. The A and B connection must be made using one pair of the cable. The 120 ohm termination jumper must be inserted on the last controller and the first controller on the bus – See Fig.1


RS485 Main






RS485 Aux




Reader, exit switch and door contact




**1104/921 Controller or
1104/926 2-Reader expansion card**



**Connection example
showing 'P60' type reader**



Fail safe (fail open) electric release





**1104/921 Controller or
1104/926 2-Reader expansion card**

iPassan readers are supplied with a varistor which must be installed as close as possible to the electric release or maglock connections. Failure to fit this component can damage the controller and automatically invalidates the controller warranty.


Power supply

+V

0V



Fail secure (fail locked) electric release





**1104/921 Controller or
1104/926 2-Reader expansion card**


Power supply

+V

0V



Maglock with double pole exit switch and break glass



Notes

