


NOTES:


- 1. This schematic is for guidance only and should not be used for installation
- 2. Maximum distance from door entry panel to 1083/20 is 200m using Cat5e cable
- 3. Maximum distance from 1083/20 to the handset is 200m using Cat5e cable
- 4. Spare cores in Cat5e cable must not be used for other services -




5. Add a cable for the electric release or maglock -




6. Add a cable if there is a keypad in the panel -




7. Add a second Cat5 cable if there is an Urmet/FDI access control reader fitted in the panel -



8. Cabling for double pole push to exit switch, double pole break glass unit and maglock -



9. Up to four handsets can be connected to ring together -







Urmet Communication & Security UK Ltd Urban Hive, Avenue West Skyline 120 Great Notley Essex CM77 7AA www.urmet.co.uk

Title 2Voice system schematic

Drawing No. UD07885 PAGE1

Date 15-11-2020

Drawn TC Checked LK Revision 01